

605-339-0575  
jfoss@foss-avi.com  
fosssecurity.com  
623 S Lyons Ave Ste 300  
Sioux Falls, SD 57106



## Concord 4 Instructions

### **Disarm the system or Cancel an accidental alarm**

Disarm button + CODE -OR- 1 button + CODE

### **Arm to Level 2—STAY \* (no motion sensors)**

Stay or 2 button

### **Arm to Level 3—AWAY \* (motion sensors on)**

Away or 3 button

### **Arm system with No Delay \* (no delay on entry doors and also silences the delay beeping)**

Stay button + 4 (no motions) or  
Away button + 4 (motions)

### **Arm system Silently \***

5 + Stay or Away

### **Disarm system Silently \***

5 + disarm + code

### **Send a Police Alarm**

Press and hold both POLICE buttons for 2 seconds.

### **Send a Medical Alarm**

Press and hold both AUXILIARY buttons for 2 seconds.

## **Send a Fire Alarm**

Press and hold both FIRE buttons for 2 seconds.

## **Bypass a sensor \*** (if there is a trouble with a particular sensor or just want one bypassed)

Indirectly (sensor open or troubled): Stay + # -OR- Away + #

Directly: Stay or Away then # + CODE + Sensor Number

## **Check the system status \*** (Anytime the panel is beeping or the \* is flashing, pressing the \* will let you know what is wrong with the system)

\*for Short status or \* + \* for Full status

## **Turn Chime on/off** (enables beeping at the panel when a door is opened)

7 + 1

## **Check Alarm Memory**

7 + 6

## **View Event History**

8 + CODE + 8