

## Replacing the battery in a TX-E611 Flood Sensor

**CAUTION!** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the manufacturer's instructions.

**WARNING!** This product contains a coin battery. If it is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Remove from the mounting bracket and backplate as shown below, then remove and replace **CR2450 3-Volt Lithium battery**.

1. Remove the sensor from its mounting bracket
2. Remove the white rubber feet on the bottom of the flood detector
3. Remove the three screws and open the case
4. Replace the battery with a CR2450 3-volt lithium battery
5. Replace the screws and rubber feet

