

## Replacing the Battery Motion Sensor QS1231

**CAUTION!** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the manufacturer's instructions.

**WARNING!** This product contains a coin battery. If it is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

### Step-by-Step Instructions :



1. Locate the sensor with a low battery on either your system panel or in the Mobile App.
3. Leaving the sensor backplate in place, open the cover by pressing the tab at the bottom of the sensor.
4. Remove the old batteries.
5. Make sure the area where the batteries are stored is clean and there is no corrosion.
6. Place 2 new AAA batteries into the sensor.
7. Put the cover back on starting with the opposite end from which it was opened. You should hear a snapping sound if it closes correctly.
8. Arm and disarm the system to clear the bypassed sensor.
9. Check if the low battery status has cleared or follow the link below for further instructions on clearing the error from the panel memory.